

TWO-WAY HANDLEBAR POSITION

The handlebar position can be adjusted by moving the handlebar lower holder.

1. Remove the handlebar upper holder bolt cap, handlebar holder bolts and holder.
2. Loosen the handlebar lower holder nuts but do not remove them.
3. Adjust the handlebar position.

2



TWO-WAY HANDLEBAR POSITION 2-2



3. Remove the handlebar assembly and turn the lower holder 90 degrees.
4. Reinstall the handlebar upper holder with their punch marks facing forward.
5. Install the upper holder bolt, tighten the forward bolts first, then the rear bolts.
6. Tighten the handlebar lower holder nuts.
7. Install the handlebar upper holder bolt caps.

TWO-WAY HANDLEBAR POSITION

The handlebar position can be adjusted by moving the handlebar lower holder.

To adjust the handlebar position:

1. Loosen the handlebar lower holder nuts but do not remove them.
2. Remove the handlebar upper holder bolt caps, handlebar holder bolts and holders.



3. Remove the handlebar assembly and turn the lower holders 90 degrees.
4. Reinstall the handlebar upper holders with their punch marks facing forward.
5. Install the upper holder bolts, tighten the forward bolts first, then the rear bolts.
6. Tighten the handlebar lower holder nuts.
7. Install the handlebar upper holder bolt caps.

