

AIR CLEANER .....	4-7	DRIVE CHAIN SLIDER .....	4-24
AIR CLEANER CASE SIDE COVER .....	3-5	DRIVE SPROCKET INSTALLATION .....	8-12
AIR CLEANER HOUSING .....	6-52	DRIVE SPROCKET REMOVAL .....	8-4
ALTERNATOR CHARGING COIL .....	16-6	DTC CODE INDEX .....	6-27
ALTERNATOR COVER INSTALLATION .....	11-11	DTC TROUBLESHOOTING .....	6-30
ALTERNATOR COVER REMOVAL .....	11-4	ECM (ENGINE CONTROL MODULE) .....	6-83
ALTERNATOR/STARTER CLUTCH SPECIFICATIONS ..	1-8	ECT SENSOR .....	6-77
BALANCER .....	12-27	ELECTRIC STARTER SPECIFICATIONS .....	1-10
BANK ANGLE SENSOR .....	6-81	EMISSION CONTROL SYSTEMS .....	1-33
BATTERY .....	16-5	ENGINE & FRAME TORQUE VALUES .....	1-12
BATTERY/CHARGING SYSTEM SPECIFICATIONS .....	1-10	ENGINE CONTROL MODULE (ECM) .....	20-11
BODY PANEL LOCATIONS .....	3-2	ENGINE DOES NOT START OR IS HARD TO START ..	22-2
BRAKE FLUID .....	4-25	ENGINE IDLE SPEED .....	4-17
BRAKE FLUID REPLACEMENT/AIR BLEEDING .....	15-6	ENGINE INSTALLATION .....	8-8
BRAKE LIGHT SWITCH .....		ENGINE LACKS POWER .....	22-3
LIGHTS/METERS/SWITCHES .....	19-25	ENGINE OIL/OIL FILTER .....	4-14
MAINTENANCE .....	4-27	ENGINE REMOVAL .....	8-5
BRAKE PAD WEAR .....	4-26	ENGINE STOP RELAY .....	6-82
BRAKE PAD/DISC .....	15-9	FLYWHEEL INSTALLATION .....	11-10
BRAKE PEDAL .....	15-29	FLYWHEEL REMOVAL .....	11-6
BRAKE SYSTEM .....	4-26	FORK .....	13-18
CABLE & HARNESS ROUTING .....	1-23	FRONT BRAKE CALIPER .....	15-23
CAM CHAIN TENSIONER LIFTER .....	9-37	FRONT FENDER .....	3-7
CAM PULSE GENERATOR .....	6-78	FRONT MASTER CYLINDER .....	15-13
CAMSHAFT .....	9-12	FRONT WHEEL .....	13-12
CHARGING SYSTEM INSPECTION .....	16-6	FRONT WHEEL/SUSPENSION/STEERING	
CHOKE OPERATION .....	4-6	SPECIFICATIONS .....	1-9
CLUTCH FLUID FILLING/BLEEDING .....	10-6	FUEL CUT-OFF RELAY .....	6-47
CLUTCH .....	10-16	FUEL LEVEL SENSOR .....	19-22
CLUTCH COVER INSTALLATION .....	10-24	FUEL LINE .....	4-5
CLUTCH COVER REMOVAL .....	10-14	FUEL LINE INSPECTION .....	6-43
CLUTCH FLUID DRAINING .....	10-6	FUEL PUMP .....	6-45
CLUTCH FLUID REPLACEMENT/AIR BLEEDING .....	10-6	FUEL SYSTEM (Programmed Fuel Injection)	
CLUTCH MASTER CYLINDER .....	10-8	SPECIFICATIONS .....	1-6
CLUTCH SLAVE CYLINDER .....	10-13	FUEL TANK .....	6-48
CLUTCH SWITCH .....	19-25	GEARSHIFT LINKAGE .....	10-25
CLUTCH SYSTEM/CLUTCH FLUID .....	4-28	GENERAL SPECIFICATIONS .....	1-4
CLUTCH/GEARSHIFT LINKAGE SPECIFICATIONS .....	1-7	GRAB RAIL/REAR COWL .....	3-5
COMBINATION METER .....	19-11	HANDLEBAR .....	13-6
COMPONENT LOCATION .....		HANDLEBAR SWITCHES .....	19-24
ALTERNATOR/STARTER CLUTCH .....	11-2	HEADLIGHT .....	19-6
CLUTCH/GEARSHIFT LINKAGE .....	10-2	HEADLIGHT AIM .....	4-27
CRANKSHAFT/TRANSMISSION/BALANCER .....	12-2	HORN .....	19-27
CYLINDER HEAD/CYLINDER/PISTON .....	9-2	HYDRAULIC BRAKE SPECIFICATIONS .....	1-10
ENGINE REMOVAL/INSTALLATION .....	8-2	IAT SENSOR .....	6-76
FRONT WHEEL/SUSPENSION/STEERING .....	13-2	IGNITION COIL .....	17-7
FUEL SYSTEM (Programmed Fuel Injection) .....	6-2	IGNITION PULSE GENERATOR .....	17-8
HYDRAULIC BRAKE .....	15-2	IGNITION SWITCH .....	19-23
REAR WHEEL/SUSPENSION .....	14-2	IGNITION SYSTEM INSPECTION .....	17-5
COOLANT REPLACEMENT .....	7-6	IGNITION SYSTEM SPECIFICATIONS .....	1-10
COOLANT TEMPERATURE GAUGE/SENSOR .....	19-19	IGNITION TIMING .....	17-12
COOLING FAN MOTOR RELAY .....	19-20	IMMOBILIZER INDICATOR .....	20-11
COOLING SYSTEM .....	4-18	IMMOBILIZER RECEIVER .....	20-12
COOLING SYSTEM SPECIFICATIONS .....	1-6	INJECTOR .....	6-67
CRANKCASE ASSEMBLY .....	12-26	INSTALLATION .....	10-14
CRANKCASE BREATHER .....	4-7	KEY REGISTRATION PROCEDURES .....	20-4
CRANKCASE SEPARATION .....	12-5	LICENSE LIGHT .....	19-10
CRANKCASE/TRANSMISSION SPECIFICATIONS .....	1-8	LIGHTS/METERS/SWITCHES SPECIFICATIONS .....	1-11
CRANKPIN BEARING .....	12-13	LUBRICATION & SEAL POINTS .....	1-19
CRANKSHAFT/CONNECTING ROD .....	12-5	LUBRICATION SYSTEM DIAGRAM .....	5-2
CYLINDER COMPRESSION TEST .....	9-7	LUBRICATION SYSTEM SPECIFICATIONS .....	1-6
CYLINDER HEAD .....	9-20	MAIN JOURNAL BEARING .....	12-10
CYLINDER HEAD COVER .....	9-7	MAINTENANCE SCHEDULE .....	4-4
CYLINDER HEAD/CYLINDER/PISTON		MAP SENSOR .....	6-75
SPECIFICATIONS .....	1-7	MIL CODE INDEX .....	6-12
CYLINDER/PISTON .....	9-31	MIL TROUBLESHOOTING .....	6-14
DIAGNOSTIC CODE INDICATION .....	20-7	MODEL IDENTIFICATION .....	1-2
DIODE .....	18-16	MUFFLER/EXHAUST PIPE .....	3-12
DRIVE CHAIN .....	4-20	NEUTRAL SWITCH .....	19-26

NUTS, BOLTS, FASTENERS.....	4-32
OIL COOLER .....	5-14
OIL PRESSURE INSPECTION .....	5-5
OIL PRESSURE SWITCH.....	19-20
OIL PUMP .....	5-9
OIL STRAINER/PRESSURE RELIEF VALVE .....	5-6
PAIR SOLENOID VALVE.....	6-86
PGM-FI (Programmed Fuel Injection) system.....	6-8
POOR HANDLING.....	22-6
POOR PERFORMANCE AT HIGH SPEED .....	22-6
POOR PERFORMANCE AT LOW AND IDLE SPEED.....	22-5
POSITION LIGHT .....	19-8
RADIATOR .....	7-10
RADIATOR COOLANT.....	4-17
RADIATOR RESERVE TANK .....	7-18
REAR BRAKE CALIPER.....	15-26
REAR FENDER .....	3-8
REAR MASTER CYLINDER .....	15-17
REAR WHEEL.....	14-6
REAR WHEEL/SUSPENSION SPECIFICATIONS.....	1-9
REGULATOR/RECTIFIER.....	16-7
SEAT .....	3-4
SECONDARY AIR SUPPLY SYSTEM .....	4-19
SERVICE INFORMATION .....	
ALTERNATOR/STARTER CLUTCH .....	11-3
BATTERY/CHARGING SYSTEM.....	16-3
CLUTCH/GEARSHIFT LINKAGE .....	10-4
COOLING SYSTEM.....	7-3
CRANKSHAFT/TRANSMISSION/BALANCER .....	12-3
CYLINDER HEAD/CYLINDER/PISTON .....	9-3
ELECTRIC STARTER .....	18-3
ENGINE REMOVAL/INSTALLATION .....	8-3
FRAME/BODY PANELS/EXHAUST SYSTEM.....	3-3
FRONT WHEEL/SUSPENSION/STEERING .....	13-3
FUEL SYSTEM (Programmed Fuel Injection).....	6-3
HYDRAULIC BRAKE.....	15-4
IGNITION SYSTEM.....	17-3
IMMOBILIZER SYSTEM (HISS).....	20-3
LIGHTS/METERS/SWITCHES .....	19-3
LUBRICATION SYSTEM .....	5-3
MAINTENANCE .....	4-2
REAR WHEEL SUSPENSION .....	14-3
SERVICE RULES .....	1-2
SHIFT FORK/SHIFT DRUM.....	12-23
SHOCK ABSORBER.....	14-13
SIDE COVER .....	3-4
SIDE STAND .....	4-29
SIDE STAND SWITCH.....	19-26
SPARK PLUG .....	4-8
SPEEDOMETER/VEHICLE SPEED SENSOR.....	19-15
STANDARD TORQUE VALUES .....	1-12
STARTER CLUTCH .....	11-7
STARTER MOTOR.....	18-6
STARTER RELAY SWITCH.....	18-15

STARTER VALVE .....	6-69
STARTER VALVE SYNCHRONIZATION .....	6-73
STATOR.....	11-4
STEERING HEAD BEARINGS.....	4-33
STEERING STEM .....	13-30
SUSPENSION.....	4-29
SWINGARM .....	14-15
SYSTEM DIAGRAM .....	
BATTERY/CHARGING SYSTEM .....	16-2
ELECTRIC STARTER.....	18-2
FUEL SYSTEM (Programmed Fuel Injection) .....	6-7
IGNITION SYSTEM .....	17-2
IMMOBILIZER SYSTEM (HISS) .....	20-2
SYSTEM FLOW PATTERN .....	7-2
SYSTEM LOCATION .....	
FUEL SYSTEM (Programmed Fuel Injection) .....	6-6
LIGHTS/METERS/SWITCHES .....	19-2
SYSTEM TESTING.....	7-5
TACHOMETER .....	19-18
TAIL/BRAKE LIGHT.....	19-10
THERMOSTAT .....	7-8
THROTTLE BODY.....	6-57
THROTTLE OPERATION.....	4-6
TP SENSOR.....	6-79
TRANSMISSION .....	12-15
TROUBLESHOOTING .....	
ALTERNATOR/STARTER CLUTCH .....	11-3
BATTERY/CHARGING SYSTEM .....	16-4
CLUTCH/GEARSHIFT LINKAGE .....	10-5
COOLING SYSTEM .....	7-4
CRANKSHAFT/TRANSMISSION/BALANCER.....	12-4
CYLINDER HEAD/CYLINDER/PISTON .....	9-6
ELECTRIC STARTER.....	18-4
FRAME/BODY PANELS/EXHAUST SYSTEM.....	3-3
FRONT WHEEL/SUSPENSION/STEERING .....	13-5
FUEL SYSTEM (Programmed Fuel Injection) .....	6-5
HYDRAULIC BRAKE .....	15-5
IGNITION SYSTEM .....	17-4
IMMOBILIZER SYSTEM (HISS) .....	20-9
LIGHTS/METERS/SWITCHES .....	19-5
LUBRICATION SYSTEM .....	5-4
REAR WHEEL SUSPENSION .....	14-5
TURN SIGNAL.....	19-9
TURN SIGNAL RELAY.....	19-28
TWO-WAY HANDLEBAR POSITION.....	2-2
VALVE CLEARANCE .....	4-9
VARIABLE AIR INTAKE CONTROL VALVE.....	6-84
WATER PUMP.....	7-15
WHEELS/TIRES .....	4-33
WIRING DIAGRAMS .....	
ED type (English, French, Germany) .....	21-3
ED type (Italian, Spanish, Dutch) .....	21-4
U type.....	21-5